























































































































































































































































---

EEPROM Corruption .....	63
Encoder Error .....	63
Error Messages .....	49
Set Point Failure .....	62
Tracking Error (RUN Mode).....	61
Tracking Error (SETUP Mode) .....	60
Valve Error.....	62
Feedback Cable.....	34
Feedback Signal, Output .....	19
Field Interface Connector, Motor Cable .....	36
Filters .....	32
Firmware Version, Controller .....	53
Flange and Accessories Kit .....	24, 25
Flange Bolts, Torque Requirements .....	30
Flexitallic Gaskets .....	30
Installation Dimensions.....	85
Flow Characteristic, Fuel Valve.....	13, 15, 29, 42
Dead Zone .....	43
Flow Coefficient, Cv .....	14
Flow Crack Point .....	42, 43
Flow Direction.....	29
Fuel Gas Filters .....	32
Fuel Gas Preparation .....	32
Hydrogen Sulphide.....	32
Fuel Gas Temperature .....	64
Fuel Valve	
Flow Characteristic.....	13, 15, 29, 42
Flow Direction.....	29
Installation Requirements .....	29
Mechanical Description .....	15
MTBF.....	107
Product Identification Nameplate .....	21
Specifications .....	77
Trim Orifices.....	42
Vent Connection .....	31
Fuel Valve (2-inch)	
Component Identification .....	94
Cv Codes .....	95
Fuel Valve (3-inch)	
Component Identification .....	93
Cv Codes .....	94
Fuel Valve Body .....	15
Fuel Valve Position Indicator	
Adjustable Guide.....	44
Machined Slot.....	43
Fuel Valve Stroke .....	42
Fuel Valve Torque .....	64
Fuel Valve Wear .....	67
Fuel Valve/Actuator Installation Dimensions	
2-inch Valve .....	82

---

---

3-inch Valve .....	83
Functional Control Diagram, Fuel Valve System.....	18, 61
Fuse and Connector Kit, Spare .....	23
Fuses .....	37
<b>G</b>	
Gaskets, Flexitallic.....	30
Installation Dimensions.....	85
Grounding Terminals.....	37
8412 Rev G and H .....	38
8412 Rev I .....	38
<b>H</b>	
Heat Dissipation, Controller .....	32
Hole Patterns, Mounting .....	104
Hydrogen Sulphide, in Fuel Gas.....	32
HYSTERESIS, SETUP Mode .....	58
<b>I</b>	
Index.....	109
Input Requirements .....	29
Inspection of Product .....	22
Installation Dimensions	
2-inch Fuel Valve/Actuator .....	82
3-inch Fuel Valve/Actuator .....	83
Controller (8412G and Previous) .....	81
Controller (8412H) .....	80
Controller (8412I) .....	79
Flexitallic Gaskets.....	85
Weld Neck Flange (2-inch Valve).....	84
Installation Requirements	
Controller .....	32
Fuel Valve .....	29
Precautions .....	27
<b>L</b>	
LCD Display .....	47
LED Indicators .....	51
Log, Events and Alarms.....	49
<b>M</b>	
Machined Slot .....	40, 43
MANUAL POSITION, SETUP Mode .....	57
MANUAL SETUP	
SET CLOSED POS .....	57
SET OPEN POS.....	57
MANUAL SETUP, SETUP Mode .....	57
MAX SP, AUTO SETUP .....	56

---



---

Mechanical Description, Fuel Valve and Actuator .....	15
Mechanical Stops, Actuator.....	16
Adjustable Guide.....	41
Machined Slot.....	40
Setup .....	40
MIN SP, AUTO SETUP .....	56
Motor Cable.....	35
Weidmuller Field Interface Connector .....	36
Mounting	
2 and 3-inch Fuel Valves .....	105
Actuator Alignment .....	30
Controller.....	32
Hole Patterns.....	104
U-bolt.....	103
U-Bolt.....	105
MTBF	
Controller.....	107
Fuel Valve .....	107
<b>N</b>	
Normal Operation, Controller .....	61
<b>O</b>	
OPEN Push Button .....	47
Open-Loop Control .....	59
Optical Encoder.....	18
Ordering Information .....	22
Output Feedback Signal .....	19
<b>P</b>	
Parts Class, Spares.....	107
PCB Switch S1 Setting	
Location.....	87
RUN Mode .....	60
SETUP Mode .....	52
Piping Connections .....	29
Position Cable .....	36
Position Feedback, Actuator.....	18
Position Indicator .....	43
Adjustable Guide.....	44
Graduations .....	44
Machined Slot.....	43
Position Signal .....	18
Resolution.....	18
Power Cable .....	37
Power Consumption.....	29
Power Failure.....	19
Power Requirements.....	29
Controller.....	29

---




---

Power Supply/Interconnect Assembly.....	90
Precautions, Installation .....	27
Precision Dowel Pin.....	40
Precision Slot Machined .....	40
Product Description.....	13
Electronic Control System.....	17
Mechanical, Fuel Valve and Actuator .....	15
Product Identification .....	20
Actuator.....	21
Controller.....	20
Fuel Valve .....	21
Protective Covers .....	28
Push Buttons .....	47
CLOSE .....	47
ESC(APE) .....	47
OPEN.....	47
SEL(ECT) .....	47
 <b>R</b>	
Receiving Product.....	22
Relays, Controller Status .....	63
Replacement Parts.....	28
Returning Equipment .....	22
RUN Mode .....	60
Normal Operation.....	61
PCB Switch S1 Setting .....	60
 <b>S</b>	
SEL(ECT) Push Button.....	47
SET CLOSED POS, MANUAL SETUP .....	57
SET OPEN POS, MANUAL SETUP .....	57
Set Point	
Configuration.....	57
Failure .....	62
SET POINT FAIL, SETUP Mode .....	58
SETUP Mode .....	52
AUTO SETUP.....	56
CONTROL ACTION .....	57
CONTROL MODE.....	59
HYSTERESIS .....	58
MANUAL POSITION.....	57
MANUAL SETUP.....	57
Menu .....	54
Notes.....	55
PCB Switch S1 Setting .....	52
SET POINT FAIL .....	58
SYSTEM CHECK.....	60
Setup, Mechanical Stops .....	40
Adjustable Guide.....	41

---

---

Machined Slot.....	40
Slot, Machined.....	40
Spares	
Actuator Parts.....	108
Controller Parts.....	108
Flange and Accessories Kit.....	24, 25
Fuel Valve Cartridges.....	107
Fuse and Connector Kit.....	23
Parts Class.....	107
Specifications	
Actuator Performance.....	76
Actuator, Electrical.....	76
Actuator, Mechanical.....	75
Controller.....	76
Environmental – Fuel Valve and Actuator.....	75
Fuel Valve, Mechanical.....	77
Operator Interface.....	77
Weights.....	78
Storage Requirements.....	22
Storage Temperature.....	22
Stroke, Fuel Valve.....	43
SYSTEM CHECK, SETUP Mode.....	60
Tracking Error.....	60

## T

Temperature, Fuel Gas.....	64
Temperature, Storage.....	22
Third-Party Approvals.....	78
Torque Requirements, Flange Bolts.....	30
Torque, Actuator.....	16
Torque, Fuel Valve.....	65
Tracking Error (RUN Mode).....	61
Tracking Error (SETUP Mode).....	60
Trim Orifices.....	42

## U

U-bolt, Mounting.....	103, 105
User Interface Panel.....	46
LCD Display.....	47
LED Indicators.....	51
Push Buttons.....	47

## V

Valve Error.....	62
Vent Connection.....	31
Vent Line, Orientation.....	31
Venting Discharge.....	31



**W**

Wear, Fuel Valve .....	67
Weidmuller Connector, Motor Cable .....	36
Weld Neck Flange Dimensions (2-inch Valve) .....	84
Wiring Details, Controller.....	88, 89, 90









### **Americas**

---

AMOT USA  
8824 Fallbrook Dr  
Houston  
Texas 77064  
USA

Tel: +1 (281) 940 1800  
Fax: +1 (713) 559 9419  
Email: sales@amotusa.com

### **Asia and Australasia**

---

AMOT China  
Rm 4102 – 4104, United Plaza  
1468 Nanjing Road West  
Shanghai 200040  
China

Tel: +86 (0) 21 6279 7700  
Fax: +86 (0) 21 5237 8560  
Email: shanghai@amot.com

AMOT Singapore  
10 Eunos Road 8 #12-06  
Singapore Post Centre  
Singapore 408600

Tel: +65 (0) 6408 6265  
Fax: +65 (0) 6293 3307  
Email: singapore@amot.com

### **Europe and Africa**

---

AMOT UK  
Western Way  
Bury St Edmunds  
Suffolk, IP33 3SZ  
England

Tel: +44 (0) 1284 762222  
Fax: +44 (0) 1284 760256  
Email: info@amot.com

AMOT Controls GmbH  
Rondenbarg 25  
22525 Hamburg  
Germany

Tel: +49 (0) 40 8537 1298  
Tel: +49 (0) 40 8537 1331  
Email: germany@amot.com

AMOT Russia  
#34 Shabolovka Street  
Building 2  
Moscow 115419  
Russia

Tel: +7 495 617 12 93  
Fax: +7 495 913 97 65  
Email: russia@amot.com